



Foot Bolt Lock Installation Instructions

Tools Required:

- Drill
 - 1/8" drill bit
 - Screws (provided with the foot bolt lock)
-

Steps:

1. Prepare the Sash:

- Take the foot bolt lock portion.
- Install it on the sash, after making any necessary height adjustments.

2. Position the Lock:



- Align the foot bolt lock on the left side of the sash.
- Slightly raise the lock so it does not rub against the track.

3. Install the Screws:



- Use the provided screws and carefully drill them into the two open holes on the right-hand side of the lock and the bottom hole on the left-hand side.
- The screws should easily go through the vinyl; be cautious not to strip them.



4. Predrill for the 4th Screw:



- For the upper left-hand screw, predrill a hole through the metal reinforcement with a 1/8" drill bit.
- This ensures the screw will go through smoothly and securely.

5. Attach the keeper:



- Align the keeper under the installed lock portion. Use the provided screws and carefully drill them into the two open holes.

6. Final Check:



- Ensure the lock is properly aligned and doesn't interfere with the sash movement.
- Test the lock by engaging and disengaging it to confirm smooth operation.